

2016 Audi Maintenance Schedule - All Models

MY 2016 Maintenance Intervals - Canada

Service Intervals

If you are not sure when you should bring your Audi in for service or which services are to be performed on your vehicle, ask your authorized Audi Service Advisor.

Service intervals in kilometers

8,000 km ¹	Standard Maintenance Service with tire rotation
25,000 km ²	Major Maintenance Service with additional items
40,000 km	Standard Maintenance Service
55,000 km	Major Maintenance Service with additional items
70,000 km	Standard Maintenance Service
85,000 km	Major Maintenance Service with additional items
100,000 km	Standard Maintenance Service
115,000 km	Major Maintenance Service with additional items
130,000 km	Standard Maintenance Service
145,000 km	Major Maintenance Service with additional items
160,000 km	Standard Maintenance Service
175,000 km	Timing Belt Replacement (Audi TTS only)
175,000 km	Major Maintenance Service with additional items
190,000 km	Standard Maintenance Service with additional item
205,000 km	Major Maintenance Service with additional items
220,000 km	Standard Maintenance Service
235,000 km	Major Maintenance Service with additional items

1) First standard maintenance service at 8,000 km or 1 year after delivery, whichever occurs first. Standard maintenance services thereafter occur at intervals of 15,000 km or 1 year after the last standard maintenance service, whichever occurs first.

2) First major maintenance service at 25,000 km or 2 years after delivery, whichever occurs first. Major maintenance services thereafter occur at intervals of 30,000 km or 2 years after the last major maintenance service, whichever occurs first.

The intervals shown in this table are based on vehicles operating under normal conditions. In case of severe conditions, such as extremely low temperatures, excessive dust, etc., it is necessary for certain operations to be carried out in between the given intervals. This applies particularly to engine oil changes and the cleaning or replacing of the air cleaner filter element.

Time-Sensitive Maintenance Items

Service interval by time (and kilometers where applicable)	Maintenance item
Every 2 years regardless of kilometers	Replace brake fluid (all vehicles)
Every 2 years regardless of kilometers	Check cloth top function and rollover protection with cloth top down (Audi A5/S5 Cabriolet-only)
Every 2 years regardless of kilometers	Crash active headrest - Check function (Audi A8 only)
Every 3 years regardless of kilometers	BorgWarner clutch - replace oil (Audi A3, Q3, Audi TT & TTS only)
Every 4 years regardless of kilometers	AdBlue® Fluid - Replace only if AdBlue® has not been filled within the last 4 years (All TDI models)



Standard Maintenance Service

First at 8,000 km or 1 year after delivery, whichever occurs first. Thereafter, every 15,000 km or one year, whichever occurs first.

- AdBlue® fluid - Fill completely with fresh fluid (24 liters max.) (All TDI models)
- Brake system - Check for damage and leaks, thickness of pads, and brake fluid level
- Brake system - Check that the vent caps are mounted on calipers and check the condition of the brake hoses
- Cooling system for electrical components: Check coolant level according to description in ElsaPro (Audi A3 e-tron® only)
- Engine oil / Oil filter - Change oil and replace filter
- Engine compartment - Check for leaks
- On-board diagnosis - Check (flex fuel vehicles only)
- Service reminder indicator display - Reset display
- Tires and spare wheel - Check for wear and damage. Check tire pressure. Reset Tire Pressure Monitoring System (TPMS)
- Water separator in fuel filter: Remove water (Audi A3 TDI and Q7 TDI models)
- Windshield washer and headlight washing system - Add fluid if necessary. Check adjustment and function
- Wiper blades - Check condition and replace if necessary

Additional item at 8,000 km or 1 year after delivery, whichever occurs first.

- Rotate tires. Reset TPMS

Major Maintenance Service (Includes All Standard Maintenance Items)

First at 25,000 km or two years, whichever occurs first. Thereafter, every 30,000 km or two years, whichever occurs first.

- 12 volt (small) side battery located in the trunk compartment on left side - Check for clean terminals (no corrosion), properly mounted housing and no damage; replace if necessary (Audi Q5 hybrid only)
- Automatic transmission and final drive - Check for leaks
- Battery - Check for clean terminals (no corrosion), properly mounted housing and no damage; replace if necessary. Also, check the acid level of battery only if the level can be seen through the housing and fill if necessary (except Audi Q5 hybrid)
- Charging socket: Check for damage and make sure the socket is dry (Audi A3 e-tron® only)
- Crash active headrest - Check function (Audi A8 only)
- Cooling system - Check coolant level and add coolant if necessary (except A3 e-tron®)
- Doors - Lubricate door hinges, straps, locks, and hood latch
- Drive shafts - Check boots
- Dust and pollen filter - Replace filter
- Exhaust system - Check for damage and leaks
- Front latch for Cabriolet roof - Lubricate (Audi A3 Cabriolet, A5 Cabriolet and S5 Cabriolet)
- Front headlights - Check adjustment
- Front lighting - Check function of parking lights, low beams, high beams, fog lights, blinkers & hazard lights
- Front and rear axle - Check for excessive play. Check dust seals on ball joints and tie rod ends
- Horn - Check function
- Instrument cluster- Check warning and indicator lights
- Interior lights - Check all interior lights and glove box compartment illumination
- Manual transmission and final drive - Check for leaks
- On-board tool kit - Check for completeness
- Panorama sunroof systems- Clean guide rails and lubricate with grease according to description in ElsaPro
- Plenum Panel - Remove cover for plenum panel to check water drain and clean if necessary (all models except Audi A3 and Q3)
- Rear lighting - Check function of brake lights (including third brake light), tail lights, back-up lights, rear fog lights, license plate lights, blinkers & hazard lights and trunk light
- Rear spoiler hinges: Lubricate according to description in ElsaPro (TT, TTS, A7, S7 & RS7 only)



Major Maintenance Service (continued)

- Road test - Check engine performance, clutch, manual/auto transmission, braking (including hand and foot brake), steering, wheels, wheel bearings, drive shaft, horn, hybrid vehicles (electric drive for operational readiness)
- Safety belts - Check clip for belt tongue and check function of all safety belts
- Snow screen for air cleaner - Clean (Audi A4, S4, allroad®, A5, A5 Cabriolet, S5, S5 Cabriolet, Audi Q5, SQ5, and Q5 hybrid only)
- Sunroof systems - Check function
- Tire repair set - Check for completeness and renewal date (where applicable)
- Underbody - Check for damage and leaks
- Visual check - Check the chassis for possible paint damage and corrosion, from the inside and outside with the doors as well as hood and trunk lids open
- Visual check - Check that the wheel house liners, underbody panelling and lines are correctly mounted

Additional Maintenance Items

Perform at 25,000 km and thereafter every 30,000 km.

- Fuel filter - Replace (All TDI models)

Perform first at 55,000 km and thereafter every 60,000 km.

- DSG/S tronic - Change ATF oil and replace transmission filter element for clutch hydraulics (A3, S3, TT, TTS, S5, S5 Cabriolet, RS 5, S6, and S7 only)
- DSG/S tronic - Change ATF oil for clutch hydraulics (Audi A3 e-tron® and A6 front wheel drive only)
- Rear sport differential - Change ATF for clutch hydraulics and differential oil (RS 7 only)
- Air cleaner³ - Clean housing and replace filter element only on the following vehicles: (S6, S7, RS7, A8 3.0L V6 TDI, A8 3.0L V6 TFSI, A8 4.0L V8 TFSI, TTS)

3) The S8 4.0L V8 TFSI engine is not included in this interval. It must be performed first at 85,000 km and thereafter every 90,000 km.

Perform first at 55,000 km or 4 years, whichever occurs first. Thereafter, every 60,000 km or 4 years, whichever occurs first.

- Brake discs - Check thickness

Perform first at 55,000 km or 6 years, whichever occurs first. Thereafter, every 60,000 km or 6 years, whichever occurs first.

- Spark plugs⁴ - Replace only on the following vehicles: (4.0L V8, A8L W12, 2.0L TFSI except Q3 only, and A3 e-Tron® with the 1.4T engine)

4) Excludes 2.0L TFSI Flex Fuel engines

Perform first at 55,000 km or 6 years, whichever occurs first. Thereafter, every 45,000 km or 6 years, whichever occurs first.

- Spark plugs - Replace (2.0L TFSI Flex Fuel engines only)

Perform first at 85,000 km and thereafter every 90,000 km.

- Air cleaner⁵ - Clean the housing and replace the filter element (except: TTS, S6, S7, RS7, A8 with the 3.0L V6 TFSI, A8 3.0L V6 TDI & A8 4.0L V8 TFSI)
- Ribbed V-belt - Replace only the belt for the compressor drive (front belt) (all vehicles with the 3.0L V6 TFSI)
- Tiptronic gear box: Change ATF (Q5 hybrid only)

5) The air cleaner replacement at this interval includes the S8 4.0L V8 TFSI engine.

Perform at 85,000 km or 6 years, whichever occurs first. Thereafter, every 90,000 km or 6 years, whichever occurs first.

- Spark plugs - Replace (Audi A3 with the 1.8l TFSI, Q3 2.0L TFSI, 3.0L V6 TFSI, and 5.2L V10 only)



Additional Maintenance Items (continued)

Perform at 115,000 km and thereafter every 120,000 km.

- Ribbed V-belt - Check condition and replace if necessary. Check tension of belt drive with a manual tensioner and retension if necessary

Perform after the first 175,000 km or 165,000 km after a Diesel Particulate Filter (DPF) replacement.

- Diesel Particulate Filter (DPF) – Check ash loading according to manufacturer work procedure; replace⁶ if necessary (All TDI models)

⁶) If DPF replacement is not necessary, perform check every 30,000 km thereafter until replacement becomes necessary.

Perform every 205,000 km.

- Timing belt - Replace. Check condition of timing belt tensioning system, dampening pulleys, and idler pulleys and replace if necessary (2.0l TDI models and Audi A3 e-tron[®] only)

Oil Capacity Chart

Model	Engine	Engine oil Approx. qty. w/filter change	Audi Oil Spec**
A3 e-tron [®]	1.4L TFSI 204hp	4.0L (4.2 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
A3	1.8L TFSI 170hp	5.2L (5.5 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
A3	2.0L TFSI 220hp	5.7L (6.0 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
A3	2.0L TDI 150hp	5.5L (5.8 qt)	VW 507 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
S3	2.0 TFSI 292hp	5.7L (6.0 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
A4	2.0L TFSI 220hp	4.5L (4.8 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
S4	3.0L V6 333hp	6.8L (7.2qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
A5	2.0L TFSI 220hp	4.5L (4.8 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
S5	3.0L V6 333hp	6.8L (7.2 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
A6	2.0L TFSI 252hp	4.7L (5.0 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40



Model	Engine	Engine oil Approx. qty. w/filter change	Audi Oil Spec**
A6	3.0L TFSI 333hp	6.8L (7.2 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
A6	3.0L TDI 240hp	6.4L (6.8 qt)	VW 507 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
S6	4.0L TFSI 450hp	8.7L (9.2 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
A7	3.0L TFSI 333hp	6.8L (7.2 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
A7	3.0L TDI 240hp	6.4L (6.7 qt)	VW 507 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
S7	4.0L TFSI 450hp	8.7L (9.2 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
RS7	4.0L TFSI 560hp	8.7L (9.2 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
A8/A8L	3.0L TFSI 333hp	6.8L (7.2 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
A8/A8L	4.0L TFSI 450hp	8.7L (9.2 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
A8L	3.0L TDI 240hp	6.4L (6.8 qt)	VW 507 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
S8	4.0L TFSI 520hp	8.7L (9.2 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
A8L	6.3L W12 500hp	11.2L (11.8 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
Q3	2.0T 200hp	4.5L (4.8 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
Q5	2.0L TFSI 220hp	4.5L (4.8 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
Q5 Hybrid	2.0L TFSI 211hp	4.5L (4.8 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
Q5	3.0 V6 272hp	6.8L (7.2 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40



Model	Engine	Engine oil Approx. qty. w/filter change	Audi Oil Spec**
Q5	3.0L TDI V6 240hp	6.4L (6.8 qt)	VW 507 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
SQ5	3.0L V6 354hp	6.8L (7.2 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
TT	2.0L TFSI 220hp	5.7L (6.0 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
TTS	2.0L TFSI 292hp	5.7L (6.0 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40
TTR	2.0L TFSI 220hp	5.7L (6.0 qt)	VW 502 00** Use synthetic oil SAE 5W-40, SAE 5W-30 or SAE 0W-40