

2018 Audi Maintenance Schedule - All Models

MY 2018 Maintenance Intervals - Canada

Service intervals in kilometres												
	15km	30km	45km	60km	75km	90km	105km	120km	135km	150km	165km	180km
Standard Maintenance (Every 1 year) ¹	X		X		X		X		X		X	
Major Maintenance (Every 2 years) ²		X		X		X		X		X		X
Additional Maintenance Items	Refer to the Additional Maintenance Items Table below											

1) First standard maintenance service at 15,000 km or 1 year after delivery, whichever occurs first. Standard maintenance services thereafter occur at intervals of 30,000 km or every 2 years after the last standard maintenance service, whichever occurs first.

2) First major maintenance service at 30,000 km or 2 years after delivery, whichever occurs first. Major maintenance services thereafter occur at intervals of 30,000 km or every 2 years after the last major maintenance service, whichever occurs first.

NOTE: The intervals shown in this table are based on vehicles operating under normal conditions. In case of severe conditions, such as extremely low temperatures, excessive dust, etc., it is necessary for certain operations to be carried out in between the given intervals. This applies particularly to engine oil changes and the cleaning or replacing of the air cleaner filter element.

Check all completed items

Standard Maintenance

- Brake system - Check the thickness of the disc brake pads
- Engine Oil and Oil filter - Change oil and replace filter
- Service Reminder Indicator display - Reset display
- Tire Repair Kit - Check and record the completeness and expiration date (if equipped)

Major Maintenance (Includes Standard Maintenance Service)

- Safety belts- Check function
- Body - Check for damage and corrosion
- Brake system - Check condition of brake hoses and the presence of the bleeder caps
- Charging socket - Check for contamination and damage (A3 e-tron only)
- Convertible Top - Lubricate latch mechanism (A5/S5/RS 5 Cabriolet only)
- Cooling system for electrical components - Check coolant level according to description in ElsaPro (A3 e-tron only)
- Door hinge and door latch - Lubricate
- Engine cooling system - Check freeze protection and coolant level (All except e-tron)
- Engine, Transmission, Final drive, Steering - Visual inspection for leaks and damage
- Exterior lighting - Check front and rear lights, turn signals, cornering lights, reverse lights, license plate lights, and hazard warning lights
- First aid kit - Check and enter expiration date YYYY / MM _____
- Front and rear axle/suspension components - Check dust seals on ball joints and tie rod ends; check for excessive play
- Front lid latch - Lubricate (R8, R8 Spyder only)
- Fuel tank flap system - Check the water drain (R8, R8 Spyder only)
- Headlights - Check adjustment
- Hood safety catch - Lubricate (A3, A6, A7, A8, Q3, Q7, and R8 only)
- Horn - Check function
- Instrument cluster - Check warning and indicator lights
- Interior lights - Check all interior lights, trunk lights, and glove box compartment illumination
- Oil filler area - Check water drain (R8, R8 Spyder only)



Major Maintenance (continued)

- Panoramic sunroof systems - Check function (if equipped) (All except A8)
- Panoramic sunroof systems - Clean guide rails and lubricate with grease according to description in ElsaPro (if equipped) (A8 only)
- Plenum chamber and water drain valves: Check for dirt. (A6, A7, A8 and Q7 only)
NOTE: Time spent cleaning of item is a separate charge for service time
- Road test - Check engine performance, clutch, manual/auto transmission, braking (including hand and foot brake), steering, wheels, wheel bearings, driveshaft, horn, hybrid vehicles (electric drive for operational readiness)
- Rollover protection - Check the rollover protection when the convertible top is open (R8 Spyder and A3 Cabriolet only)
- Spare tire - Check condition and tire inflation pressure, adjust if necessary (if equipped)
- Spoiler - Lubricate rear spoiler (A7, S7, RS 7, and TT only)
- Sunroof systems - Check function (if equipped)
- Tires - Check condition and tire tread wear. Check and record the tread depth
- Tires - Check tire inflation pressure and adjust if necessary
- Underbody - Check the covers and inner fender liners for damage and correct fit
- Warning triangle - Check if present (if equipped)
- Windshield washer and headlight washing system - Add fluid if necessary. Check adjustment and function
- Wiper blades - Check condition and replace if necessary

Additional Maintenance Items		
Work to be completed	Interval	Model Application
<input type="checkbox"/> Air filter - Replace	Every 60,000 km	RS7, A8 LWB only
<input type="checkbox"/> Air filter - Replace	Every 90,000 km	All vehicles except RS7 and A8 LWB
<input type="checkbox"/> AWD clutch - Change fluid (if equipped)	Every 3 years	A3 quattro, S3, RS 3, Q3 quattro, TT Coupe 2.0T, TTS Coupe 2.0T, TT Roadster 2.0T, TT RS
<input type="checkbox"/> Battery - Connected gateway - Replace (if applicable)	Every 7 years	A4, S4, A4 allroad, A5, S5, RS 5, 3.0T, Q5, SQ5, Q7
<input type="checkbox"/> Brake fluid - Change	Every 2 years	All
<input type="checkbox"/> Dust and Pollen filter - Replace	Every 30,000 km or 2 years, whichever occurs first	All
<input type="checkbox"/> Front axle differential - Change fluid (if equipped)	Every 180,000 km or 10 years, whichever occurs first	R8 only
<input type="checkbox"/> Rear Axle, quattro Sport - Change oil and ATF fluid changes	Every 60,000 km	RS 7, RS 7 performance only
<input type="checkbox"/> Rear Axle, quattro Sport - Change oil and ATF fluid changes	Every 90,000 km	RS 5 only
<input type="checkbox"/> Ribbed V-belt - Replace	Every 90,000 km	A6 3.0T, A6 Competition 3.0T, A7 3.0T, A7 Competition 3.0T, A8 3.0T, Q7 3.0T
<input type="checkbox"/> Spark plugs - Replace	Every 45,000 km or 3 years, whichever occurs first	RS 3, RS 5, RS 7 performance, S8 plus, TT RS only



Additional Maintenance Items		
Work to be completed	Interval	Model Application
<input type="checkbox"/> Spark plugs - Replace	Every 60,000 km or 6 years, whichever occurs first	A3, S3, A3 e-tron, A4, S4, A4 allroad, A5, S5, A6 2.0T, S6 4.0T, S7 4.0T, RS 7 4.0T (except RS 7 performance), A8 L 4.0T V8 (except S8 plus), Q5, SQ5, Q7 2.0T, TT 2.0T, TTS
<input type="checkbox"/> Spark plugs - Replace	Every 90,000 km or 6 years, whichever occurs first	A6 3.0T, A6 Competition 3.0T, A7 3.0T, A7 Competition 3.0T, A8 L 3.0T, Q3, Q7 3.0T, R8
<input type="checkbox"/> S-Tronic transmission - Change fluid	Every 120,000 km	A3 Sedan 2.0T B-cycle, A3 Cabriolet 2.0T B-cycle, S3
<input type="checkbox"/> S-Tronic transmission - Change fluid and filter replace	Every 60,000 km	A3 Cabriolet 2.0T (non B-cycle), A3 Sedan 2.0T (non B-cycle), S6 4.0T, S7 4.0T, TT Coupe 2.0T, TTS Coupe 2.0T, TT Roadster 2.0T, R8
<input type="checkbox"/> S-Tronic transmission - Change fluid	Every 60,000 km	A3 e-tron, RS 3, A4 2.0T, A4 allroad, A5 2.0T, S5 3.0T, (Coupe/Cabriolet/Sportback), A6 2.0T, Q5 2.0T, TT RS

MY 2018 Oil Capacity Chart

Model	Engine	Engine oil Approx. qty. w/filter change	Audi Oil Spec**
A3	2.0L TFSI	5.7L (6.0 qt)	502/504** Castrol EDGE® Professional® 5W40
A3 B-cycle	2.0L TFSI	5.7L (6.0 qt)	508** Castrol EDGE® Professional® 0W20 Long Life IV
RS 3	2.5L TFSI	7.1L (7.5 qt)	502/504** Castrol EDGE® Professional® 5W30 LL03
S3	2.0L TFSI	5.7L (6.0 qt)	502/504** Castrol EDGE® Professional® 5W40
A3 e-tron	1.4L TFSI	4.0L (4.2 qt)	502** Castrol EDGE® Professional® 5W40
A4	2.0L TFSI	5.2L (5.5 qt)	502/504** Castrol EDGE® Professional® 5W40
A4 B-cycle	2.0L TFSI	5.2L (5.5 qt)	508** Castrol EDGE® Professional® 0W20 Long Life IV



Model	Engine	Engine oil Approx. qty. w/filter change	Audi Oil Spec**
S4	3.0L TFSI	7.25L (7.7 qt)	508** Castrol EDGE® Professional® 0W20 Long Life IV
A5	2.0L TFSI	5.2L (5.5 qt)	502/504** Castrol EDGE® Professional® 5W40
S5	3.0L TFSI	7.25L (7.7 qt)	508** Castrol EDGE® Professional® 0W20 Long Life IV
RS 5	2.9L TFSI	7.6L (8.0 qt)	502/504** Castrol EDGE® Professional® 5W40
A6	2.0L TFSI	4.7L (5.0 qt)	502/504** Castrol EDGE® Professional® 5W40
A6	3.0L TFSI	6.8L (7.2 qt)	502/504** Castrol EDGE® Professional® 5W40
S6	4.0L FSI	8.7L (9.2 qt)	502/504** Castrol EDGE® Professional® 5W40
A7	3.0L TFSI	6.8L (7.2 qt)	502/504** Castrol EDGE® Professional® 5W40
S7/RS7	4.0L FSI	8.7L (9.2 qt)	502/504** Castrol EDGE® Professional® 5W40
A8	3.0L TFSI	6.8L (7.2 qt)	502/504** Castrol EDGE® Professional® 5W40
A8	4.0L FSI	8.7L (9.2 qt)	502/504** Castrol EDGE® Professional® 5W40
Q3	2.0L TFSI	4.5L (4.8 qt)	502/504** Castrol EDGE® Professional® 5W40
Q5	2.0L TFSI	5.2L (5.5 qt)	502/504** Castrol EDGE® Professional® 5W40"
SQ5	3.0L TFSI	7.25L (7.7 qt)	508** Castrol EDGE® Professional® 0W20 Long Life IV
Q7	2.0L TFSI	5.2L (5.5 qt)	502/504** Castrol EDGE® Professional® 5W40
Q7	3.0L TFSI	6.8L (7.2 qt)	502/504** Castrol EDGE® Professional® 5W40
TT/TTS	2.0L TFSI	5.7L (6.0 qt)	502/504** Castrol EDGE® Professional® 5W40
TT RS	2.5L TFSI	7.1L (7.5 qt)	502/504** Castrol EDGE® Professional® 5W30 LL03
R8	5.2L V10	8.3L (8.8 qt)	502/504** Castrol EDGE® Professional® 5W40